

## Hob Shower Installation detail

To observe all of the relevant authority requirements, and to ensure ease of installation, the following instruction need to be observed paying particular attention to the fitting of both the ½ inch to 3/8 adaptor which houses the water flow control and the ½ inch MI to ½ inch FI fitting which houses the Non return valve.

### Installation Steps

- 1) Fit housing for shower in desired hob location, a 35mm hole is recommended; fasten with brass nut supplied with hard washer on the top and the rubber washer below.
- 2) Feed the shower hose through the housing with the handpiece attached to the ½ inch FI end
- 3) Once the hose is installed, attach to the other end of the hose, the following 2 fitting in this order using thread seal tape for both fittings;

First fit the 3/8 BSP Female iron x ½ BSP female brass adaptor to male threaded end of hose using thread seal tape.

Then fit the ½ BSP non return valve to the brass adaptor using thread seal tape.

- 4) Now fit this complete assembly to your water supply.
- 5) Test the fittings by turning on the water supply and make sure they are sealed and water tight.

### Important note;

You should be able to blow through the NRV fitting from the female thread end but not from the male end. If not, reverse the non return valve for correct performance.

Item # 97578B Tempesta Hob shower

Should you require any assistance with this detail, please feel free to contact Argent Technical advise hotline on 1800 356 717

