

Wall Basin Installation Instructions To Suit Evo Wall Asymmetric Basins

1. **Important;** Please inspect basin/s for any imperfections prior to installation.
2. Ensure there is bracing/ reinforcement behind the finished wall where basin is to be bolted on.
3. Mark screw hole positions at required basin height.
4. Drill holes for basin bolts and fix bolts onto wall.



5. Choose to install taps and waste assembly now for ease of access.
(This can otherwise be done after Step 7)
6. Place basin in position onto the bolts, insert plastic bushes and metal washer, and retain with fixing nut.
7. NOTE: If required, use the wedges provided on the underside of the basin between the basin and the wall to optimise the top levelled surface prior to fully fastening the basin.



Examples of Installed
wedge where required

