



Bath / Basin Spout - Special Installation Method

Applies to the following spouts:

Zen bath / basin spout – 106400 / 105400

Vue bath / basin spout – 108400 / 108200 / 108100

These spouts feature a 15mm long spigot with ½ “ BSP female iron thread that requires one of the following installation techniques;

For New Installations

- 1) Rough in/ install the ½ BSP thread for the spout, so that it is flush or just below flush of the finished wall surface. (once fitted, use a thread cap or similar device protruding from the wall to ensure the plaster/ tilers do not sheet over the BSP thread)
- 2) Ensure there is at least 18mm of thread accessible behind the finished wall to install the spout during fit off.
- 3) The hole surrounding the thread spigot must be greater than 30mmØ and less than 35mm Ø with the thread located centrally. (Critical for Zen spouts)
- 4) Apply liquid thread seal (like Loxeal 58.11) to the internal thread of the spout and also to the ½ BSP outlet and fit the spout.

For Retro Fit Renovations

- 1) This detail applies where the in wall combination/ pipe work is not being replaced.
- 2) Remove existing spout, check that the hole surrounding the ½ BSP thread is not smaller than 30mmØ or greater than 35mmØ, (Critical for Zen spouts) check also that there is at least 18mm of thread available behind the finished wall.
- 3) **If either of the above do not apply, these spouts may not be suitable to install.**
- 4) Using a ½” BSP nipple cutting tool, trim the ½ BSP thread so that it is flush with the finished wall. Confirm there is 18mm of thread behind the wall.
- 5) Apply liquid thread seal (like Loxeal 58.11) to the internal thread of the spout and also to the ½ BSP outlet and fit the spout.

Should you need any additional advice, please contact the Argent Technical advice hotline on 1300 356 717.