B270-000 Bette Enamel Touch up tube

Instructions for Bette Enamel repair:

- 1. Clean the affected area of rust, fat and dirt
- 2. Rough up the area to be repaired with sandpaper, avoid touching the non effected areas surrounding the damage
- 3. Spread the touch up paint on this area very lightly and let it dry
- 4. Repeat this procedure until the area is replenished
- 5. Many light coats with repeated applications will ensure the best result, make sure each coat has adequate time to dry in between coats, this can take up to 6 hours depending on conditions