

## ISLAND BATH INSTALLATION INSTRUCTIONS

Approved wet seal membrane should be applied in-between the wall sheeting and the tiles.

### INSTALLATION DIAGRAM

