

<u>Top-Fix Soft close seat installation procedure</u>



<u>Step 1.</u>

Insert nylon toggles into the holes in the toilet pan



Step 2.

Hold toggle by the loop at the top and push the plastic plate down onto the pan so that it is a secure fit.



Step 3

Break excess toggle material off by moving it backwards and forwards a few times.



Step 4.

Attach toilet seat hinge posts to the pan; but do not tighten them as this stage.



Step 5.

Test fit the seat to ensure it is a good fit on the pan & the hinge posts, remove the seat and tension the hinge posts so they are well fastened. (i.e. They should be secure and not move)

Step 6.

Place the hinge post cover plates in position and refit seat. Test that the soft close action is working.

Technical helpline – 1800 356 717