

# PACE CLOSE COUPLED TOILET SUITE INSTALLATION GUIDE

## IMPORTANT:

PLEASE INSPECT YOUR NEW TOILET SUITE BEFORE INSTALLATION TO ENSURE NO DAMAGE HAS OCCURRED DURING TRANSIT.

IF DAMAGE HAS OCCURRED, OR VISIBLE DEFECTS EXIST, DO NOT PROCEED WITH INSTALLATION AND ADVISE ARGENT IMMEDIATELY.

## PRIOR TO INSTALLATION

Argent recommends a qualified trade person fit your Toilet Suite.

Please note, Argent will not be liable for the cost of installation or removal of the toilet and the warranty will be voided if damage occurred during or after installation.




## A ROUGH IN

S Trap Toilet requires a 145 mm set-out from the finished wall.

### IMPORTANT:

This suite is not suitable for off-set pan connectors greater than 20 mm as this can cause the pan to syphon during flushing or may diminish the overall flushing performance.

AS:2887 specifies that the waterway of the pan connector shall allow the passage of a sphere diameter of 72 mm +or- 1 mm.



## B PAN INSTALLATION

1. Place the toilet pan into position ensuring that the outlet is connected to the pan collar.
2. Mark and measure where the pan to floor fastening brackets are required.
3. Remove the toilet pan and drill the holes to fasten the supplied brackets. Check the pan fits.
4. Re-Position the pan over the pan collar and fix the pan with screws and covers (do not overtighten).
5. Apply a bead of silicon around the pan (after cistern has been installed and checked for water fastness)
6. Allowing appropriate curing time for the sealant.

## C CISTERN INSTALLATION

1. Position the cistern seal over the nut on the outlet valve on the underside of the cistern
2. Lift the cistern onto the pan, lining up cistern with the holes in the pan.
3. Using the fixings provided, tighten the cistern to the pan evenly but do not overtighten.
4. Connect the cistern to a stop tap using the appropriate plumbing fittings.
5. Ensure that the inlet water pressure does not exceed 500 KPA as per AS/NZS3500

## D SEAT INSTALLATION

1. Install the seat with the manufacturers instructions provided.

## CONTENTS:

WELS 4 STAR CLOSE COUPLED PAN  
MATCHING CISTERN WITH SOFT CLOSE SEAT  
PAN FIXINGS

## IMPORTANT:

IF DAMAGE HAS OCCURRED, OR VISIBLE DEFECTS EXIST, DO NOT PROCEED WITH INSTALLATION

NO CLAIMS WILL BE ACCEPTED AFTER INSTALLATION HAS COMMENCED.